

OPERATIONS START (follow my instructions)



HOIST Clench and unclench fingers to 'inch' load



STOP



EMERGENCY STOP




LOWER SLOWLY



LOWER FASTER







SLEW IN DIRECTION INDICATED

JIB UP JIB DOWN


DERRICKING JIB



TELESCOPING BOOM



CRANE MOVEMENT use both hands





CEASE OPERATIONS

